




User Manual



Terra 800




Step 1: Install the tires



No.	Part Name	QTY
1	Body	1
2	Tire pin	2
3	Tire shaft	2
4	Tire	2


Step 2: Install the handlebar frame



No.	Part Name	QTY
1	Hexagon socket, Head screw, M16X130-N	1
2	Pin	1
3	Handelbar frame	1
4	Tighten the handle	1




Step 3: Install the wire barrel



No.	Part Name	QTY
1	Main body	1
2	Counter component	1
3	Line barrel	1
4	Wire barrel, Swivel sleeve	2
5	Line barrel, Limit sleeve	2
6	Single arm bolt	3




Step 4: Install the steering wheel



No.	Part Name	QTY
1	Pass-through mechanism	1
2	Steering wheel	1
3	Single arm bolt	1



Step 5: Install the blade



No.	Part Name	QTY
1	Thread embedding machine blade	1