


Cable layer machine - Spare parts exploded view



Cable layer machine - Spare parts list

N0.	Name	N0.	Name	N0.	Name
1	Brake handle	38	2.sldasm-Part-257	75	Large washer 5
2	Wheel	39	A813 belt	76	Spring washer 5
3	Wheel axis	40	Main axis pulley	77	Key5X25
4	T-shaped frame	41	M8*120 hex bolt	78	Sprocket
5	Blade frame	42	M8*80 hecolt	79	Washer6
6	Index plate	43	M16*130 screws	80	Spring washer 6
7	Brake	44	Blade axis	81	Large washer 8
8	Engine	45	Mud scraper	82	Washer 8
9	Gearbox cable	46	Axis sleeve	83	Spring washer 8
10	Outer pipe weldment	47	Cable fitting	84	Washer 10
11	Tensioner cable	48	Cable locate	85	Spring washer 10
12	Pipe rack	49	Brake frame	86	Washer 16
13	Handle	50	Spring	87	Axel washer 25
14	Crank weldment	51	Single-arm bolt	88	Axel washer 52
15	Engine frame	52	Clip pin	89	Bearing6005
16	Tensioner pulley	53	Pressure spring	90	Bearing 16005
17	Roller rack	54	Gearbox pulley	91	Screw M5X12
18	Rotate sleeve	55	A635 belt	92	Bolt M5X16
19	Steering wheel	56	Right locate	93	M5*25 screw
20	Swivel cable	57	Blade	94	M6 hex bolt
21	Wire runner	58	Head bolt	95	M5*25 hex screw
22	Cable pipeline	59	Elastic spring	96	M6*16 lock nut
23	Sprocket frame	60	Tail cover	97	M6*16 hex nut
24	Sprocket weldment	61	M8 clover bolt	98	M6*20 flange bolt
25	Pin	62	Spacer	99	M6*35 hex bolt
26	M10*45 special bolt	63	Ball		
27	U shaft	64	Cover plate	101	M6 lock nut
28	M6*70 hex bolt	65	Gearbox	102	M8*20 hex bolt
29	Guard fitting	66	Gearbox spacer	103	M8*25 hex bolt
30	Guard plate	67	Blade fastener	104	Screw M8X25
31	Plastic cover	68	Roller	105	M8X25 hex nut
32	Handle cover	69	Limit spacer	106	M10 hex nut
33	Friction disk	70	Counter	107	M10*45 screw
34	Ring	71	Counter fitting		
35	Pad	72	Counter frame		
36	Roller fitting	73	Cable frame		
37	Bearing base	74	653 chain		