













User Manual







My Robot Home Plus

Screws:


- (A)  Ø3.0*40 4+1 Pcs
- (B)  M6*30 4 Pcs
- (C)  Ø3.5*30 12+1 Pcs
- (D)  Ø3.5*25 13+1 Pcs
- (E)  Ø3.0*18 8+1 Pcs

- (F)  2 Pcs
- (G)  2 Pcs
- (H)  2 Pcs (Spare)
- (I)  10cm 2 Pcs
- (J)  5*5cm 2 Pcs


- (K)  2 Pcs
- (L)  1 Pcs
- (M)  1 Pcs




1 Side panel x2 Pcs




2 Back panel x1 Pc




3 Front panel x1 Pc




4 Roof x2 Pcs




5 Roof cap x1 Pc



6 Wood bar x1 Pc




7 Wood side bar x2 Pcs




8 Metal bar x1 Pc




9 Metal side bar x2 Pcs



10 Metal middle bar x2 Pcs



11 Counterweight iron plate x2 Pcs




12 White PVC sign x1 Pcs


BEFORE STARTING THE INSTALLATION:

1. For the best result, Auto-mow recommends placing the garage on concrete, brick, or similar flat and hard surface.
2. If installed on grass, Auto-Mow recommends that you put small bricks below on all 4 corners, to support the garage, and to make sure the garage will not sink into the ground.


Step 1




Step 2




Step 3



Step 4



Step 5




Remark:

Remember to tighten the nut on the metal post - on both sides of the wooden panel.

The metal posts must be completely fixed so that they cannot move individually.


Step 6



First, insert the iron bar with a hole side into the side panel marked with L, and then put the other side into the panel mark R. Push the iron bar to the bottom to R side until the hole of the iron bar is exposed, and insert the pin M into the hole to fix it.

Step 7


D  Ø3.5*25 3pcs



Use 3 pcs of screw D to attach the roof cap.

Step 8


K  2 Pcs



Use 2 pcs of screw L to add the White PVC Sign if desired.

Step 9


Adjust the level feet below the garage, so the port does not touch the ground/grass



Remark:


We also have the Angle Bracket with long spikes. (Part J & Part H)
If you want to fix the house to the ground,
please use screw D to connect the Angle.
Bracket (H) to the house.
Make sure the long spikes (J) are fixed in the ground.

Step 1 - Adjust the mechanism to the docking station



Place the robot inside the Garage and adjust the 2 poles to fit the docking station and the robotic lawn mower.

Step 2 - Fit the string to adjust the tention of the automatic door.



Close the port using a rock or similar, and adjust the wires to fit the position between the door, robot and docking station.

TROUBLESHOOTING - If the door cannot fully open or close:

1. Inspect the level of the feet beneath the garage.
2. Adjust the mechanism angle towards the door to apply more pressure on the rods for complete closure.
3. If the door still does not fully open or close, repeat step 2 and adjust the mechanism towards the docking station.

Note: The position of the panels may affect the mechanism; adjusting them could resolve the issue.